

LINETRAXX® VMD420

Voltage and frequency monitor

for monitoring of 3(N)AC systems up to 0...500 V for undervoltage, overvoltage, underfrequency, overfrequency, phase sequence, phase failure, asymmetry



LINETRAXX® VMD420

Multi-functional voltage relay for frequency, overvoltage, undervoltage, phase sequence, phase failure and asymmetry monitoring in 3(N)AC systems



Device features

- Undervoltage, overvoltage and frequency monitoring in 3(N)AC systems 0...500 V
- Asymmetry, phase failure and phase sequence monitoring
- Various monitoring functions selectable
 U, > U, < f, > f
- Start-up delay, response delay and delay on release
- · Adjustable switching hysteresis
- r.m.s. value measurement (AC+DC)
- Digital measured value display via multi-functional LC display
- Preset function (automatic setting of basic parameters)
- · LEDs: Power On, Alarm 1, Alarm 2
- Measured value memory for operating value
- · Continuous self monitoring
- Internal test/reset button
- Two separate alarm relays (one changeover contact each)
- N/C or N/O operation and fault memory behaviour selectable
- Password protection for device setting
- · Sealable transparent cover
- Two-module enclosure (36 mm)
- Push-wire terminal (two terminals per connection)
- RoHS compliant

Approvals







Product description

The multi-functional VMD420 series voltage relay is designed to monitor the frequency, undervoltage and overvoltage and the voltage between two threshold values in 3(N)AC systems. The voltages are measured as r.m.s. values. The currently measured value is continuously shown on the LC display. The measured value required to trigger the alarm relay is stored. Due to adjustable response times, installation-specific characteristics, such as device-specific start-up procedures, short-time voltage fluctuations, etc. can be considered. The devices require an external supply voltage.

Typical applications

- Monitoring of voltage-sensitive machines and electrical installations
- Switching machinery and equipment on and off at a certain voltage level
- · Monitoring of stand-by and emergency supply systems
- Supply voltage monitoring of portable loads
- Protection of three-phase motors against phase failure and phase open-circuit
- · Transformer protection, asymmetrical load can be recognised

Function

Once the supply voltage is applied, the start-up delay "t" begins. Measured voltage and frequency values changing during this time do not influence the switching state of the alarm relays.

The devices feature two separately adjustable measuring channels (overvoltage/undervoltage). When the measuring quantity exceeds the response value ("Alarm 1") or falls below the response value ("Alarm 2"), the time of the response delays " $t_{on1/2}$ " begins. Once the response delay has elapsed, the alarm relays switch and the alarm LEDs light up. When the measuring value exceeds or falls below the release value (response value plus hysteresis) after the alarm relays have switched, the selected release time " t_{off} " begins. When " t_{off} " has elapsed, the alarm relays switch back to their initial position. When the fault memory is activated, the alarm relays remain in alarm position until the reset button "R" is pressed. When the fault memory is set to continuous mode, the alarm parameters remain stored, even on failure of the supply voltage.

Preset function

After connecting the device for the first time, the nominal system voltage will be determined (PrE run), and the response values for overvoltage and undervoltage as well as for underfrequency and overfrequency will automatically be set. When no voltage is determined within a nominal system voltage range (PrE run), the response values will be set to the minimum or maximum voltage. In this case, the message "AL not SET" appears on the display. As long as no button is pressed, a nominal system voltage is being searched cyclically (PrE run). If a button is pressed, the search will be interrupted and the message "AL not SET" disappears. In this case, the appropriate response values have to be set in the menu. When activating the frequency monitoring function, the preset frequency will automatically be stored.

Standards


The VMD420 complies with the requirements of

• DIN EN 45545-2.





Operating elements



- 1 Power On LED "ON" (green); lights when supply voltage is applied and flashes in the event of system fault alarm
- 2 Alarm LED "AL1" (yellow), lights when the set response value >U/<f/>f/>f >f/Asy/PHS is exceeded and flashes in the event of system fault alarm
- 3 Alarm LED "AL2" (yellow), lights when the set response value >U/<f/>f/>f >f/Asy/PHS is exceeded and flashes in the event of system fault alarm
- 4 Multi-functional LC display
- 5 Test button "T": Arrow up button: to change the measured value display, move upwards in the menu or to change parameters
- To call up the self test: press the button "T" >1.5 s

 6 Reset button "R":
 Arrow down button: to change the measured value display, move downwards in the menu or to change parameters


To delete stored alarms: press the button "T" >1.5 s


7 - "MENU" button: Enter button: to confirm the measured value indication or to confirm changed parameters


To call up the menu system, press the button "T" >1.5 s Press the ESC button >1.5 s to abort an action or to return to the previous menu level

When the menu item LEd is activated, the alarm LED "AL1" indicates that K1 is in the alarm state. When "AL2" lights up, K2 is in the alarm position.

Wiring diagram







- 1 L1, L2, L3, (N) Connection to the system/load to be monitored
- **2 A1, A2** Supply voltage U_s (see ordering information)
- 3 **11, 12, 14** Alarm relay "K1": Configurable for *U*<*/U*>*/f*<*/f*>/Asy/PHS/ERROR
- 4 **21, 22, 24** Alarm relay "K2": Configurable for *U*</*U*>/*f*</*f*>/Asy/PHS/ERROR
- 5 Line protection according to IEC 60364-4-43:6 A fuse recommended. If being supplied from an IT system, both lines have to be protected by a fuse.



Ordering information

Supply voltage ¹⁾ U s		Туре	Art. No.		
AC	DC	AC/DC	.,,,,	Screw-type terminal	Push-wire terminal
1672 V	9.694 V, 15460 Hz	-	VMD420-D-1	B93010005	B73010005
-	-	70300 V, 15460 Hz	VMD420-D-2	B93010006	B73010006


¹⁾ Absolute values


Accessories

Type designation	Art. No.	
Mounting clip for screw mounting (1 piece per device)	B98060008	

Dimension diagram XM420

Dimensions in mm





Technical data

Insulation coordination acc. to IEC 60664-1/IE	C 60664-3
Rated insulation voltage	400 V
Rated impulse voltage/pollution degree	4 kV/III
Protective separation (reinforced insulation) between	en
(A1, A2) -	(N, L1, L2, L3) -(11, 12, 14) -(21, 22, 24)
Voltage test acc. to IEC 61010-1:	
(N, L1, L2, L3) -(A1, A2), (11, 12, 14)	3.32 kV
(N, L1, L2, L3) -(21, 22, 24)	2.21 kV
(A1, A2) -(11, 12, 14) -(21, 22, 24)	2.21 kV
Supply voltage	
VMD420-D-1:	
Supply voltage U _S	AC 1672 V/DC 9.694 V
Frequency range $U_{\rm S}$	15460 Hz
VMD420-D-2:	
Supply voltage $U_{\rm S}$	AC/DC 70300 V
Frequency range U _s	15460 Hz
Power consumption	≤ 4 VA
Measuring circuit	
Measuring range (rms value) (L-N)	AC 0288 V
Measuring range (rms value) (L-L)	AC 0500 V
Input impedance (burden) L1-N, L2-N, L3-N	1 ΜΩ
Input impedance (burden) N	n.a.
Rated frequency f_{n}	15460 Hz
Frequency display range	10500 Hz

Response values		
Type of distribution system	3(N)AC/3AC (3AC)*	
Undervoltage $U < (Alarm 2)$ (measurement method: $3Ph/3n$)	AC 6500/6288 V	
Overvoltage $U > (Alarm 1)$ (measurement method: 3Ph/3n)	AC 6500/6288 V	
Resolution of setting <i>U</i>	1 V	
Preset function for 3AC measurement:		
Undervoltage U $<$ (0.85 Un)* for Un $=$ 400/208 V	340/177 V	
Overvoltage U > (1.1 Un)* for Un = 400/208 V	440/229 V	
Preset function for 3(N)AC measurement:		
Undervoltage $U < (0.85 U_n)^*$ for $U_n = 230/120 \text{ V}$	196/102 V	
Overvoltage $U > (1.1 U_{\rm n})^*$ for $U_{\rm n} = 230/120 \text{ V}$	253/132 V	
Asymmetry	530 % (30 %)*	
Phase failure	by setting the asymmetry	
Phase sequence clockwise/s	anticlockwise rotation (off)*	
Relative uncertainty, voltage at 50/60 Hz	± 1.5 %, ± 2 digits	
Relative uncertainty, voltage in the range 15460 Hz	$\pm 3\%$, ± 2 digits	
Hysteresis <i>U</i>	140 % (5 %)*	
Underfrequency Hz <	10500 Hz**	
Overfrequency Hz >	10500 Hz**	
Resolution of setting f (10.099.9 Hz)	0.1 Hz	
Resolution of setting f (100500 Hz)	1 Hz	
Preset function:		
Underfrequency for $f_n = 16,7/50/60/400 \text{ Hz}$	15.7/49/59/399 Hz	
Overfrequency for $f_n = 16,7/50/60/400 \text{ Hz}$	17.7/51/61/401 Hz	
Hysteresis, frequency Hys Hz	0.12 Hz (0.2 Hz)*	
Relative uncertainty, frequency range 15460 Hz	±0.2 %, ±1 digit	



Technical data (continued)

Specified time	
Start-up delay t	0300 s (0 s)*
Response delay $t_{on1/2}$	0300 s (0 s)*
Delay on release toff	0300 s (0.5 s)*
Resolution of setting t , $t_{on1/2}$, t_{off} (010	
Resolution of setting t , $t_{on1/2}$, t_{off} (109)	9 s) 1 s
Resolution of setting t , $t_{on1/2}$, t_{off} (100	300 s) 10 s
Operating time, voltage tae	≤ 140 ms
Operating time, frequency t_{ae}	≤ 335 ms
Response time t _{an}	$t_{\rm an} = t_{\rm ae} + t_{\rm on1/2}$
Recovery time t _b	≤ 300 ms
Displays, memory	
Display	LC display, multifunctional, not illuminated
Display range measured value	AC/DC 0500 V
Operating uncertainty, voltage at 50 Hz/6	0 Hz ±1.5 %, 2 digits
Operating uncertainty voltage in the rang	
Operating uncertainty, frequency in the ra	
History memory (HiS) for the first alarm va	alue data record measured values
Password	off/0999 (off/ 0)*
Fault memory (M) alarm relay	on/off/con (on)*
Switching elements	
Number	2 x 1 changeover contacts (K1, K2)
Operating principle	N/C operation n.c. or N/O operation n.o.
	(undervoltage $U <$, asymmetry Asy, N/C operation n.c.)*
	L (overvoltage $U >$, asymmetry Asy, N/O operation n.o.)*
Electrical endurance, number of cycles	10,000
Contact data acc. to IEC 60947-5-1:	3,722
Utilisation category	AC-13 AC-14 DC-12 DC-12 DC-12
Rated operational voltage	230 V 230 V 24 V 110 V 220 V
Rated operational current	5 A 3 A 1 A 0.2 A 0.1 A
Minimum contact load (relay manufacture	
Environment/EMC	instanted to the state of the s
FMC	EN 61326-1
Ambient temperatures:	
Operation	-25+55 ℃
Transport	-25+70°C
Storage	-25+55 ℃
Classification of climatic conditions a	cc. to IEC 60721
(related to temperature and relative humi	idity)
Stationary use (IEC 60721-3-3)	3K23 (no condensation, no formation of ice)
Transport (IEC 60721-3-2)	2K11
Long-term storage (IEC 60721-3-1)	1K22
Classification of mechanical condition	ns acc to IFC 60721
Stationary use (IEC 60721-3-3)	3M11
Transport (IEC 60721-3-2)	2M4
Long-term storage (IEC 60721-3-1)	1M12
Option "W" data different from the s	
Classification of climatic conditions acc. to	
	3 (condensation and formation of ice is possible)
Classification of mechanical conditions acc	
Stationary use (IEC 60721-3-3)	3M12
Stationary use (IEC 00721 3 3)	JM12

Connection	
Connection type	screw-type terminal or push-wire terminal
Connection	screw terminals
Connection properties	
rigid	0.24 mm ² (AWG 24 12)
flexible	0.22.5 mm ² (AWG 2414)
Two conductors with the same cross section	
rigid/flexible	0.21.5 mm ² (AWG 2416)
Stripping length	89 mm
Tightening torque, terminal screws	0.50.6 Nm
Connection	push-wire terminals
Connection properties	
rigid	0.22.5 mm ² (AWG 2414)
flexible	
without ferrules	0.752.5 mm ² (AWG 1914)
with ferrules	0.21.5 mm ² (AWG 2416)
Stripping length	10 mm
Opening force	50 N
Test opening, diameter	2.1 mm
Other	
Operating mode	continuous operation
Mounting	any position
Degree of protection, internal components (DII	N EN 60529) IP30
Degree of protection, terminals (DIN EN 60529	IP20
Enclosure material	polycarbonate
Flammability class	UL94 V-0
DIN rail mounting acc. to	IEC 60715
Screw mounting	2 x M4 with mounting clip
Documentation number	D00137

()* = factory setting

Weight

 \leq 150 g

^{** =} The technical data can only be ensured in the operating range of the nominal frequency 15...460 Hz.



Bender GmbH & Co. KG

Londorfer Straße 65 • 35305 Grünberg • Germany Tel.: +49 6401 807-0 • info@bender.de • www.bender.de

